

Substrate Notes: It is manufactured as smooth and woodgrain sheets consisting of wood fibres bound with natural lignin. Weathertex is a highly durable exterior grade hard board use for the exterior cladding of residential and commercial buildings. It is 97% timber and 3% natural wax with no glues, resins or formaldehydes. In its natural un-primed form, it comes with a **10** year guarantee from the manufacturer.

Substrate Preparation Notes: Ensure the Weathertex is thoroughly clean and dry before commencing. If there is any doubt, measure moisture content which must be less than 15% before staining or finishing can commence. Examine the surface for the presence of grease, oil, wax, tannin, building marks, or other contaminants. Use a stiff bristle brush to remove dirt and mortar splashes. Soap and water may be used where appropriate, then left to dry.

Coating System Summary

Prep Coat	AUDW0690: Cabot's Deck Clean
Coating Application Details	<ul style="list-style-type: none"> Shake contents before use. Test on a small area to determine effectiveness and strength required. Add one part Cabot's Deck Clean to four parts water in a plastic bucket and mix well. For stubborn stains use a stronger solution. Apply generously to the timber with a brush or broom. Scrub vigorously. Leave the solution on the timber for 10-20 minutes. Rinse off the surface with water using a garden hose. Avoid allowing to dry out. Severely stained surfaces may need an additional treatment and more vigorous scrubbing.
HINT	Cabot's Deck Clean is not a paint remover, however it may remove some old and weathered coatings from timber.

1st Coat: AUDW1311	Cabot's Aquadeck
2nd Coat: AUDW1311	Cabot's Aquadeck
Optional: AUDW1311	Cabot's Aquadeck
Coating Application Details	<ul style="list-style-type: none"> Brush or pad applicator. Stir thoroughly with a broad paddle before and during use. Apply liberally along the length of the board including exposed edges and end grain by brush or pad applicator. The initial milky colour helps with even product application, drying to a semi-transparent finish. Apply a minimum of two coats allowing 2 hours between applications.
MAINTENANCE	Re-apply as the timber changes colour or when water repellence diminishes due to weathering. Follow surface preparation instructions.